

Tenant Guide: Changing a Lightbulb


Tenants are responsible for changing light bulbs in properties. Below are some tips to help you with this.

How To:

STANDARD LIGHTBULB

Most lights will have these lightbulbs. To change these, firstly turn the light off and simply unscrew and screw the new bulb back in.


To make sure you're buying the right replacement you can bring the old bulb into the shop or take a picture beforehand.



BATHROOM LIGHTS

Some bathroom lights have these type of fittings. They can be changed by unscrewing the screws in the cover and then installing a new bulb.

The bulb needed for this bathroom light is a **16W 4 Pin 2D Lamp**.



SPOTLIGHTS

These are the fittings used for spotlights. They will either unplug or unscrew.

Similarly, you can bring the old bulb or a picture into the shop to find the right replacement.

