


Tenant Guide: Storage Heaters

Storage heaters work by charging the heater at night when the electric is cheaper so it can then be used for the rest of the day.

How To Use:

CHECK THE SWITCH IS ON

They normally have a light above them which turns on when the electricity switches over at night and the heater charges




INPUT

This charges the heater at night.

The input buttons should be turned on to the maximum number (normally 5) during the colder winter months. During warming months this can be turned down to 1 or turned off. If off or 1 it will only have a minimal charge.

It will take 24 hours to initially charge the heater if it has been turned off.



INPUT


OUTPUT

This controls the heat coming from the heater.

For maximum heat turns to the highest value.

For minimal heat please turn to the lowest setting.

Please remember that the a storage heater will have a limited charge so should not be left on full at all times.



OUTPUT